
## MJ FABER www.mjfaber.com

## **INSTALLATION**

- Column version for anchorage on floor and water supply from floor.
- Version column water supply with fixed attack 1/2"M under the base of the column.
- Scheme valid for nr. 1 or 2 lines of water supply.

from A to B: flexible tube (for example polyethylene)



V. 13-4-2016

